

DRIVE AWAY CHECKLIST - BEFORE YOU HIT THE ROAD

- Close all cupboards by carefully pushing in the hinge and ensuring it is snapped close
- Bolt table and drawer
- Bolt rear garage drawers
- Turn off water pump
- Turn off water heater
- Turn off inverter
- Check you have removed connectors and hose from campsite tap
- Take oven trays out of oven and store
- Secure anything that is loose
- Place the step into the van
- Ensure bench and seat timber covers are in their secure position
- Make sure awning is properly secured back into lock position and rod is inside van
- Ensure propane gas cylinders are secure and not able to roll around
- Don't store items in the sink, they will rattle when moving
- Quick check of inventory list to make sure nothing has been left behind
- Close grey water tap

NIGHTTIME CHECKLIST - BEFORE YOU GO TO SLEEP

- Store outside items inside if you can (to prevent any theft)
- Wind awning in (wind may pick up through the night and the noise will wake you up)
- Place window covers on rear barn doors and side door
- Close curtains (the window film is transparent at night with lights on)
- Lock van with remote from inside (remember to unlock in the morning when you step outside otherwise alarm will go off)
- Turn off inverter to save power
- Turn off water pump
- Turn off water heater
- If you wish to extend the bed into double position watch the [Instruction Video](#)

FINAL CHECKLIST - BEFORE YOU RETURN AURORA TO HOME BASE

- Petrol tank must be full on return
- Empty and clean the toilet (this is an absolute must)
- Make sure the van is left in the same condition as you found it
- Check inventory list to ensure nothing was left behind
- Dispose of all your rubbish responsibly